


AERODROME GROUND MOVEMENT
AND AIRCRAFT PARKING CHART

TWR 121.700

KYIV/Antonov-2



TAXIWAYS:

Width: Main TWY - 21m, TWY1 - 22.5m, TWY2 - 21m

Surface: Concrete all TWY

Strength: Main TWY, TWY1 - PCN 60/R/C/X/T,
TWY2 - PCN 59/R/C/X/T

CAUTION:

1. Taxiing AN-12,22,124,225, IL-76 via TWY and apron is performed by inner engine traction.
2. Taxiing AN-22,124,225(Code 4E) only via TWY1.

STANDS:

Surface: Aircraft stands 1,2,3,5,6 - concrete
Strength: PCN 60/R/C/X/TSurface: Aircraft stands 7-12 - concrete
Strength: PCN 62/R/C/X/T

Aircraft stands 1,2,3,5,6 - for AN-124

Aircraft stands 7,8,9 - for AN-72,74,140,148

Aircraft stands 10-12 - for AN-24,26,32

INS COORDINATES FOR AIRCRAFT STANDS

1 - 50°35'43" N	030°12'15" E	8 - 50°35'23" N	030°12'28" E
2 - 50°35'40" N	030°12'16" E	9 - 50°35'22" N	030°12'29" E
3 - 50°35'38" N	030°12'18" E	10 - 50°35'21" N	030°12'29" E
5 - 50°35'33" N	030°12'22" E	11 - 50°35'19" N	030°12'30" E
6 - 50°35'30" N	030°12'24" E	12 - 50°35'18" N	030°12'32" E
7 - 50°35'24" N	030°12'28" E		

CHANGE: KYIV/Antonov-2; ARO; PCN; STANDS 13,14 are deleted.